

 a Gusto

[www.agusto.pl](http://www.agusto.pl)

*Classic*

GOURMET



Size / Code



**flat plate round**

*Teller flach*

assiette plate ronde

- 15 cm / CLFP15
- 17 cm / CLFP17
- 19 cm / CLFP19
- 21 cm / CLFP21
- 24 cm / CLFP24
- 27 cm / CLFP27
- 29 cm / CLFP29
- 31 cm / CLFP31
- 33 cm / CLFP33



**deep plate**

*Teller tief*

assiette creuse

- 24 cm - 62.5 cl / CLDP24
- 26 cm - 77.5 cl / CLDP26
- 30 cm - 117.5 cl / CLDP30



**square salad bowl**

*Salatschale quadratisch*

saladier carré

- 12 cm - 26 cl / CLSB12
- 14 cm - 40 cl / CLSB14
- 16 cm - 50 cl / CLSB16
- 18 cm - 64 cl / CLSB18
- 21 cm - 90 cl / CLSB21




**flat square plate**

*Teller flach quadratisch*

assiette plate carrée

- 24 cm / CLSP24
- 27 cm / CLSP27
- 30 cm / CLSP30




**flat plate rectangular**

*Teller flach rechteckig*

assiette plate rectangulaire

- 21 x 8 cm / CLRP21
- 23 x 7 cm / CLRP23
- 26 x 8 cm / CLRP26
- 29 x 10 cm / CLRP29
- 33 x 23 cm / CLRP33
- 38 x 21 cm / CLRP38



Size / Code



**soup bowl stackable**  
*Suppentasse stapelbar*  
tasse à bouillon empilable  
30 cl / CLCS30



**salt shaker**  
*Salzstreuer*  
salière  
/ CLSS01



**pepper shaker**  
*Pfefferstreuer*  
poivrier  
/ CLPS01



**egg cup**  
*Eierbecher*  
coquetier  
5 cl / CLEG01



**coffee pot with lid**  
*Kaffeekanne mit Deckel*  
cafetière et couvercle  
35 cl / CLCP35

Size / Code



**tea pot with lid**  
*Teekanne mit Deckel*  
théière et couvercle  
40 cl / CLTP40



**sugar bowl with lid**  
*Zuckerdose mit Deckel*  
sucrier et couvercle  
27 cl / CLSU27



**creamer**  
*Milchkännchen*  
pot à lait  
25 cl / CLCR25  
15 cl / CLCR15



**cup non stackable**  
*Tasse nicht stapelbar*  
tasse non empilable  
9 cl / CLCU09  
20 cl / CLCU20  
23 cl / CLCU23  
28 cl / CLCU28



**cup stackable**  
*Tasse stapelbar*  
tasse empilable  
9 cl / CLSC09  
20 cl / CLSC20  
23 cl / CLSC23



**saucer**  
*Untertasse*  
soucoupe



13 cm / CLSA13  
15 cm / CLSA15  
17 cm / CLSA17

