



Size / Code



flat plate with rim
Teller flach mit Fahne
assiette plate à aile

24 cm / NOFP24
28 cm / NOFP28
32 cm / NOFP32



flat plate rimless
Teller flach ohne Fahne
assiette plate sans aile

12 cm / NOLD12
14 cm / NOLD14
16 cm / NOLD16
20 cm / NOLD20



deep plate
Teller tief
assiette creuse

20 cm / NODP20



bowl
Schale
bol

12 cm / NOBW12
14 cm / NOBW14
16 cm / NOBW16



mug
Mug
mug

33 cl / NOMG33



cup
Tasse
tasse

9 cl / NOCU09
20 cl / NOCU20
23 cl / NOCU23



cup
Tasse
tasse

30 cl / NOCU30

Size / Code



saucer
Untertasse
soucoupe

9 cl / NOSA1
20 cl / NOSA2
23 cl / NOSA3
30 cl / NOSA4



mise en bouche cup
Mise en bouche Tasse
mise en bouche à aile

9 cl / NOMB1



coffee pot
Kaffeekanne
cafetière

40 cl / NOCP40
100 cl / NOCP100



teapot
Teekanne
théière

40 cl / NOTP40
100 cl / NOTP100



creamier / jug
Milchkännchen
crémier / carafe

15 cl / NOCR15
50 cl / NOCR50



pepper shaker
Pfefferstreuer
poivrière

/ NOPS01



salt shaker
Salzstreuer
salière

/ NOSS01



mini plate with rim
Mini-Teller mit Fahne
mini assiette à aile

6 cm / NOBD01